

BENQ DV SERIES LCD TV IR CODES

	Power 00FF	TV/CATV 52AD	Aspect 54AB	Info 45BA
2	PIP/PBP 56A9	Sleep 53AC	Freeze 55AA	Back Light 58A7
3	PIP AUDIO 4CB3	i 4DB2	CH +/- 4EB1	Preset 4FB0
4	Input 10EF	44BB	Menu 12ED	
5	1CE3	Enter 51AE	48B7	
6	Favorite 11EE	1DE2	Exit 13EC	
7	Volume + 1.90E+07	Mute 43BC	Channel + 5CA3	
8	Volume - 15EA	MTS 42BD	Channel - 14EB	
9	1 04FB	2 05FA	3 5FA0	
10	4 07F8	5 08F7	6 09F6	
11	7 0AF5	8 0BF4	9 0CF3	
12	100 0DF2	0 03FC	Return 0FF0	